

ClearSonic GoboPac 20 Instructions

Parts Included: (1) A18-2, (2) S1, (8pcs) Adhesive Velcro

1. Remove paper masking from A18-2 ClearSonic Panel
2. Attach Velcro approximately 3" from the corner of each panel in the A18-2 (see picture). Allow Velcro to set-up overnight before attaching SORBER baffles to ensure a more permanent bond.
3. Attach S1 SORBER baffles.

Additional clear panels and SORBER baffles can be added to create a complete enclosure if more isolation is needed.

www.clearsonic.com
1-800-888-6360

