

ClearSonic GoboPac 40 Instructions

Parts Included: (1) A4-2, (2) S3, (8 pcs) Velcro

1. Remove paper masking from A4-2 ClearSonic Panel
2. Put S3 SORBER Baffles in position and attach velcro approximately 3" in from each corner (see picture). Allow velcro to set up overnight to ensure a more permanent bond.
3. Attach S3 SORBER Baffles.

Additional Clear Panels and SORBER baffles can be added to create a complete enclosure if more isolation is needed.

www.clearsonic.com
1-800-888-6360

