

ClearSonic GoboPac 50 Instructions

Parts Included: (1) A5-2, (2) S3, (2) S1, (16pcs) Velcro

1. Remove paper masking from A5-2 ClearSonic Panel
2. Place S3 SORBER baffles in position and attach Velcro to ClearSonic panel approximately 3" in from each corner. (see picture)
S1 SORBER baffles can be placed directly above S3s or at microphone height to reduce reflection. Allow SORBER to set-up overnight to ensure a more permanent bond.
3. Attach SORBER baffles.

Additional clear panels and SORBER baffles can be added to create a complete enclosure if more isolation is needed.

www.clearsonic.com * 1.800.888.6360

