

ClearSonic GoboPac 70 Instructions

Parts Included: (1) A5-2, (1) AX18-2 (2) S3, (2) S2, (2) S1, (24pcs) Velcro

1. Remove paper masking from A5-2
ClearSonic Panel
2. Attach AX18 Height extenders to the top of the A5-2.
3. Place S3 SORBER baffles in position and attach Velcro to ClearSonic panel approximately 3" in from each corner. (see picture)
4. S2 SORBER baffles attach directly above S3s.
5. S1 baffles can be placed above S2s, or attached to the AX18 height extenders as shown. Allow SORBER to set-up overnight to ensure a more permanent bond.

Additional clear panels and SORBER baffles can be added to create a complete enclosure if more isolation is needed.

www.clearsonic.com * 1.800.888.6360

